

Release Notes for Cisco ConfigMaker Version 2.6 Application

These Release Notes provide information about using the Cisco ConfigMaker V2.6 application and contain the following sections:

- [Introduction](#)
- [Key Features](#)
- [What's New in Version 2.6](#)
- [System Requirements](#)
- [Supported Cisco IOS Software Releases](#)
- [Supported Devices and Modules](#)
- [Current Documentation](#)
- [Caveats / Troubleshooting](#)
- [Obtaining Cisco Documentation](#)
- [Obtaining Technical Assistance](#)

To download the application or obtain more information about Cisco ConfigMaker, see the Cisco ConfigMaker Home Page on the Internet at the following URL: <http://www.cisco.com/go/configmaker>.

Introduction

Cisco ConfigMaker is an easy-to-use Microsoft Windows 98, Windows Me, Windows 2000, Windows XP, and Windows NT 4.0-based application that configures Cisco routers, switches, hubs, and other devices. Using a graphical user interface (GUI), you draw your network and then Cisco ConfigMaker creates the Cisco IOS configuration files for the devices on your network without requiring knowledge of the Cisco IOS command-line interface (CLI). In addition, you can use Cisco ConfigMaker as an off-line tool. You can draw and configure your entire network without having the devices on-hand until you are ready to deliver the configuration files to them.

Cisco ConfigMaker does not configure every IOS parameter or support every IOS feature. Rather, it helps you get your device up and running by supporting the most common features.





(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

To start Cisco ConfigMaker, double-click the Cisco ConfigMaker icon on your desktop, or select **Start > Programs > Cisco ConfigMaker V2.6** from the Windows task bar.

Key Features

Feature	Cisco ConfigMaker Support
Devices	<ul style="list-style-type: none"> • Routers—Cisco 800, 1000, 1600, 1700, 2500, 2600, 3600, and 4000 (excluding routers with token ring) • Switches—Cisco 1548, 1548M Micro Switch 10/100 • Hubs—Cisco 1538, 1538M, Cisco FastHub 412, 412M, 424, 424M • Micro Hub 10/100 Stacks—Cisco Micro Hub Stack, Cisco FastHub Stack • Other—Cisco Cache Engine (only configures Web Cache Communication Protocol (WCCP) version 1 on the router)
Cisco IOS	<ul style="list-style-type: none"> • Routers—Cisco IOS Release 11.2 or higher • Other devices—any release
LAN Connections	Ethernet, Fast Ethernet
WAN Connections	<ul style="list-style-type: none"> • ISDN BRI, ISDN PRI, ISDN leased-line (for Cisco 1603 and 1604 only) • Frame relay, Point-to-Point Protocol (PPP), High Level Data Link Control (HDLC), asynchronous, PPP over Ethernet (PPPoE) for Cisco 1700 series routers only, and voice line • POTS (for Cisco 800 series routers)
Routing Protocols	EIGRP, RIP version 2, Static Routing (IP only)
Routed Protocols	IP, IPX, AppleTalk Phase 2
Virtual Private Network (VPN)	<ul style="list-style-type: none"> • Configures IPSec and Internet Key Exchange (IKE). • Uses pre-shared key method for authentication; configure hashing method, encryption method, security association (SA) timeout values. • Draws VPN connections between point-to-point sites.
Quality of Service (QoS)	<ul style="list-style-type: none"> • Configures QoS settings on WAN interfaces to prioritize voice traffic. • Configures Committed Access Rate (CAR) to limit bandwidth for certain sites and applications.

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Firewall	<p>Cisco IOS Firewall feature set</p> <ul style="list-style-type: none"> Context-Based Access Control (CBAC) Global timer values DOS attach thresholds Java blocking Access lists Enable/disable audit trail <div>  <p>Note If you do not have the Cisco IOS firewall feature set, ConfigMaker configures access lists only.</p> </div> <div>  <p>Note ConfigMaker applies firewall configuration to the router connected to the Internet or corporate network or any <i>one</i> router if there is no Internet or corporate network.</p> </div>
Voice	<ul style="list-style-type: none"> Supports voice-over-IP (VoIP) connection to telephones, facsimiles, PBX, and Public Switched Telephone Network (PSTN). Supports an analog telephone connection to the Cisco 803 and 804 routers. Supports 2BRI-NT/TE voice interface cards (VICs) on Cisco 1751 router only. Configures QoS settings on WAN interfaces to prioritize traffic. Caller ID capability on VIC-2FXO-M1, VIC-2FXO-M2, VIC-2DID/FXS, and VIC-2FXS (for 1700 series only). Direct Inward Dialing (DID) capability on VIC-2DID/FXS.
Addressing	Network Address Translation (NAT), Easy IP (Phase 1)
Backup	Backs up a Frame Relay, PPP, HDLC, or ISDN leased line connection with a dial-up, ISDN, or another serial connection.
Simple Network Management Protocol (SNMP)	Configures read community string, read-write community string, and SNMP trap manager.
Dynamic Host Control Protocol (DHCP)	Configures DHCP server or DHCP relay.
CSU/DSU	Configures CSU/DSU module (not supported on ISDN PRI network modules).
Configuration Delivery	<ul style="list-style-type: none"> Delivers using the console port. Delivers over the network if device has an IP address.
Other Configurations	<ul style="list-style-type: none"> Number of virtual terminals Message-of-the-day (MOTD) banner IP domain name lookup HTTP server

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Other Features	<ul style="list-style-type: none"> • AutoDetect Device Wizard—automatically identifies your device. • IP subnet calculator—calculates IP and subnet masks. • Ping device—pings any address on your network. • Issue show commands—runs show commands on your router. • WAN configuration worksheets—assists in gathering data for your connection. • Instant Upgrade—easily upgrades Cisco ConfigMaker. • Cisco ConfigMaker Tutorial—guide to using Cisco ConfigMaker.
System Requirements	<ul style="list-style-type: none"> • 80486 or Pentium-class computer • Windows 98, Windows Me, Windows 2000, Windows XP, or Windows NT 4.0 with at least Service Pack 3 • 16 MB RAM • 20 MB hard disk space • 800 x 600 pixels display with 256 colors

Benefits

- Sets up your router by simply configuring a few wizards. This requires no knowledge of the Cisco IOS CLI.
- Connects you to the internet with the following features:
 - IPSec and IKE to create a tunnel between two sites for a VPN
 - Committed Access Rate (CAR) for QoS in bandwidth management
 - Cisco IOS firewall and access lists for security
 - Network Address Translation (NAT) and Easy IP for addressing
 - WCCP version 1 for redirecting web traffic to the Cisco Cache Engine to reduce downloading time
- Configures your data network to support VoIP with the following features:
 - Telephones, faxes, Private Branch Exchange (PBX) systems and/or the PSTN
 - QoS for VoIP
- Incorporates a router with an existing configuration into your network by using the new Read Configuration Wizard.
- Contains an extensive online help system, context-sensitive help, and a tutorial on how to use Cisco ConfigMaker.

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

What's New in Version 2.6

The new features in Cisco ConfigMaker V2.6 application are as follows:

The following features are new to the Cisco ConfigMaker V2.6 application:

- Configuration of the Cisco 1721 router
- Configuration of the Cisco 1760 router
- Configuration of the WIC-1ENET interface card in any of the WIC slots in a Cisco 1700 series modular router
- Addition of sample configuration files

System Requirements

Cisco ConfigMaker has the following minimum and recommended system requirements:

- Minimum System Requirements
 - 80486 or Pentium class computer
 - Minimum of 32MB of RAM and 20 MB of hard-disk space
 - SVGA monitor with a minimum of 800 x 600 pixel display and 256 colors
 - Windows 98, Windows Me, Windows 2000, Windows XP, or Windows NT 4.0 with at least Service Pack 3
- Recommended Requirements
 - Netscape navigator 4.0 or higher or Microsoft Internet Explorer 4.0 or higher
 - Internet connection on PC running Cisco ConfigMaker

Supported Cisco IOS Software Releases

Cisco ConfigMaker supports routers running Cisco IOS Release 11.2 or above. It supports any version of the hubs, switches, and the Cisco Cache Engine.

Supported Devices and Modules

Cisco ConfigMaker supports the following Cisco devices, network modules, WAN interface cards (WICs), and voice interface cards (VICs):

Table 1 *Cisco Devices*

Series	Routers
Cisco 800 series	801, 802, 803, 804, 805, 811, 813
Cisco 1000 series	1003, 1004, 1005
Cisco 1600 series	1601, 1602, 1603, 1604, 1605
Cisco 1700 series	1710, 1720, 1721, 1750, 1751, 1760

*(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL***Table 1** *Cisco Devices (continued)*

Series	Routers
Cisco 2500 series	2501, 2503, 2505, 2507, 2509, 2509-RJ, 2511, 2511-RJ, 2514, 2516, 2520, 2522, 2524
Cisco 2600 series	2610, 2611, 2620, 2621
Cisco 3600 series	3620, 3640
Cisco 4000 series	4000, 4500-M, 4700, 4700-M

Table 2 *1600 Network Interface Cards*

WICs	
1 Serial	1 ISDN BRI (U, S/T)
1 56/64-kbps CSU/DSU	1 ISDN BRI (S/T) LL (Cisco 1603 and 1604 only)
1 T1 CSU/DSU	

Table 3 *1700 Network Interface Cards*

WICs	
1 Serial	1 T1 CSU/DSU
2 Serial	2 Async/sync
1 56/64-kbps CSU/DSU	1 ISDN BRI (U, S/T)
1 Ethernet	1 ADSL WIC (hardware detection only)
VICs (for Cisco 1750, Cisco 1751, and Cisco 1760 routers only)	
2 Voice FXS	2 Voice BRI-NT/TE
2 Voice FXO	2 Voice E/M
2 Voice FXO-M1	2 Voice FXO-M2
2 Voice FXO-M3	2 Voice DID/FXS

Table 4 *2524 Network Interface Cards*

WICs	
5-in-1 Serial	2-wire 56/64-kbps CSU/DSU
T1 CSU/DSU	4-wire 56/64-kbps CSU/DSU
ISDN BRI (U, S/T)	

*(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL***Table 5 2600 Network Interface Cards**

Network Modules	
1 Ethernet	2 E1 ISDN PRI
4 Ethernet	4 Async/sync
4 ISDN BRI (U, S/T)	8 Async/sync
8 ISDN BRI (U, S/T)	16 Async
1 T1 ISDN PRI	32 Async
2 T1 ISDN PRI	1-slot VIC
1 E1 ISDN PRI	2-slot VIC
WICs	
1 Serial	1 T1 CSU/DSU
2 Serial	2 Async/sync
1 56/64-kbps CSU/DSU	1 ISDN BRI (U, S/T)
VICs	
2 Voice FXS	2 Voice E/M
2 Voice FXO	

Table 6 3600 Network Interface Cards

Network Modules		
4 Ethernet	1 10/100 Ethernet, 2 T1/ISDN PRI	4 Async/sync
1 Ethernet, 2 WAN slot	1 10/100 Ethernet, 1 E1/ISDN PRI	8 Async/sync
2 Ethernet, 2 WAN slot	1 10/100 Ethernet, 2 E1/ISDN PRI	16 Async
1 Fast Ethernet	1 T1 ISDN PRI	32 Async
Compression module	2 T1 ISDN PRI	1-slot VIC
4 ISDN BRI (U, S/T)	1 E1 ISDN PRI	2-slot VIC
8 ISDN BRI (U, S/T)	2 E1 ISDN PRI	
WICs		
1 Serial	1 56/64 kbps CSU/DSU	1 T1 CSU/DSU
1 ISDN BRI (U, S/T) {WIC - 1B}	1 ISDN BRI (U, S/T) {WIC36-1B}	
VICs		
2 Voice FXS	2 Voice FXO	2 Voice E/M

Table 7 4000 Network Interface Cards

Network Modules		
2 Ethernet	4 ISDN BRI (U, S/T)	2 Serial
6 Ethernet	8 ISDN BRI (U, S/T)	4 Serial
1 Fast Ethernet	1 T1 ISDN PRI	2 Serial, 16 Async/sync
	1 E1 ISDN PRI	

*(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL***Table 8 Hubs and Switches**

Series	Hubs
Cisco 1500 series	Cisco 1538, 1538M Micro Hub 10/100
Cisco FastHub 400 series	Cisco FastHub 412, 412M, 424, 424M
Cisco Micro Hub stack	Cisco Micro Hub 10/100 stack
Series	Switches
Cisco 1500 series	Cisco 1548, 1548M Micro Switch 10/100

Table 9 Other Devices Supported by Cisco ConfigMaker

Nonconfigurable Devices	
Internet	Dial-in PCs (modem), refers to one or more PCs
Corporate network	Dial-in PCs (ISDN), refers to one or more PCs
Ethernet LAN	Host
Voice Devices	
Telephone	Fax machine
Private Branch Exchange (PBX)	Public Service Telephone Network (PSTN)
Internet/Intranet Devices	
Cisco Cache Engine (only configures WCCP on routers)	

Current Documentation

The following documents are available for Cisco ConfigMaker:

- *Accessing the Cisco ConfigMaker V2.6 Application* is the only hard-copy document included with the product. This document lists the key features and system requirements, and it provides downloading instructions for the Cisco ConfigMaker V2.6 application.
- *Getting Started with Cisco ConfigMaker* is an online-only document. This document provides information about installing the software and adding devices, LAN segments, and connections.
- An extensive online help system and an online tutorial that shows how to use Cisco ConfigMaker.

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Caveats / Troubleshooting

- I do a *Read Configuration* on my router. The next time I deliver to it, Cisco ConfigMaker says the passwords are not correct. The asterisk shows a different amount of characters than my actual passwords.
Workaround: By default, password encryption is enabled on the router. When it reads the configuration, the encrypted passwords are read in and stored. In this case, Cisco ConfigMaker no longer stores the actual (unencrypted) password. Simply enter your password and delivery will go through.
- I run the Cisco ConfigMaker Tutorial and while it's loading, I click in the Cisco ConfigMaker window. The tutorial window is put in the background. The colors are not correct when you click on the tutorial.
Workaround: To fix the color problem, switch between the Cisco ConfigMaker window and the tutorial window again. Cisco ConfigMaker requires at least a 256-color display.
- In the Firewall Wizard, if you allow access to all services or deny access to all services, there is no warning about requiring ICMP access in both directions (client to server and server to client).
- On a Cisco 1005 or Cisco 1605, I configure the serial interface for async, which this IOS image supports, and then change the interface to sync. I deliver the configuration using network delivery. It does not change the interface to sync.
Workaround: Either use console delivery or recreate the device again.
- I deliver the configuration to a Cisco 1548M switch and it fails.
Workaround: The Cisco 1548M switch requires a slower baud rate to communicate with this device. Log into the console using a telecommunications program like Windows HyperTerminal. Set the baud rate to 2400. Now select the device in Cisco ConfigMaker and press the F5 key to see the configuration. Press Ctrl-A to select all of the text and Ctrl-C to copy the text to the clipboard. Then paste the contents of the clipboard in your console window. In HyperTerminal, this is Ctrl-V. [CSCdm28809]
- I cannot remove the default SNMP community strings on the Cisco 1548M switch. When I remove the community strings, the community string public is still set for the read community string and the string private is still set for the read/write community string.
Workaround: To remove the community strings entirely, log into the device and enter no snmp-server community <string>. [CSCdm30548]
- On Windows 95/98, the Deliver Configuration Wizard Preview page is missing the Delete, Move Up, and Move Down buttons.
Workaround: Select the devices you want to deliver before running the Deliver Configuration Wizard. You will not be able to specify the order of delivery. [CSCdk23390]
- For the Cisco 800 routers, Cisco ConfigMaker does not configure the ISDN connection for more than one telephone number.
Workaround: Manually enter IOS commands to configure the ISDN connection for other telephone numbers by using "Append config commands..." option in the Configuration tab in the Device Properties dialog box. [CSCdk64411]
- AutoDetect or read back the configuration from the router 17xx loaded with the IOS image set c1700-bk8no3r2sy-mz.122-1b.bin and then deliver the configuration. The following error occurs while delivering the configuration to the router:

```
Context      : Interface configuration mode
Command     : ip kerberos source-interface any
Error       :      ^
Invalid input detected at '^' marker.
```

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Workaround: This is because of an IOS bug and has been fixed in the IOS version 12.2 and later. Following are some of the integrated versions: 12.2(03.04)PB, 12.2(00.18)S, 12.1(05)XV02, 12.2(00.10)PI01, 12.2(00.08)PI01, 012.002(000.010), 12.1(05)YB 12.2(00.08)T. [CSCdv07448]

- I configured the 1751 router's Fast Ethernet Interface for a PPPoE Connection to Internet and delivered the configuration to the router. The PPPoE Configuration doesn't work.

Workaround: This is because of an IOS bug. The workaround is to configure PPPoE on 10BaseT (WIC-1ENET) interface and use Fast Ethernet interface for LAN connection. [CSCdu20199]

- I configured a DID-FXS interface in FXS mode in my router and read back the configuration after administratively shutting down the interface through CLI. In the Network Diagram, the interface is in DID Trunk mode as connected to PSTN instead of FXS mode.

Workaround: Configure the interface in no shutdown stage. Log into the device and enter the command "no shutdown" under the corresponding voice interface. [CSCdv28664]

- I entered the enable secret password in the Passwords page of the Device Properties with the option "Password fields contains encrypted password" checked. Then I tried to deliver the configuration to my router.

The following error occurred while delivering the configuration to the router:

```
Context : Global configuration mode
Command : enable secret 5 mypassword
Error    :
ERROR :The secret you entered is not a valid encrypted secret
```

Workaround: Enter your enable secret password in the Passwords page of the Device Properties with the option "Password fields contains encrypted password" unchecked, the delivery will go through. [CSCdv33622]

For help on troubleshooting other problems, select **Help > Troubleshooting Guide...** from the menu bar of the Cisco ConfigMaker application.

Obtaining Cisco Documentation

The following sections explain how to obtain documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following URL:

<http://www.cisco.com>

Translated documentation is available at the following URL:

http://www.cisco.com/public/countries_languages.shtml

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package, which is shipped with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco product documentation from the Networking Products MarketPlace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

If you are reading Cisco product documentation on Cisco.com, you can submit technical comments electronically. Click **Leave Feedback** at the bottom of the Cisco Documentation home page. After you complete the form, print it out and fax it to Cisco at 408 527-0730.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, use the response card behind the front cover of your document, or write to the following address:

Cisco Systems
Attn: Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC Web Site.

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you to

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages
- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

You can self-register on Cisco.com to obtain customized information and service. To access Cisco.com, go to the following URL:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two types of support are available through the Cisco TAC: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Inquiries to Cisco TAC are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

Which Cisco TAC resource you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

Cisco TAC Web Site

The Cisco TAC Web Site allows you to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to the following URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco services contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to the following URL to register:

<http://www.cisco.com/register/>

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL

If you cannot resolve your technical issues by using the Cisco TAC Web Site, and you are a Cisco.com registered user, you can open a case online by using the TAC Case Open tool at the following URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, it is recommended that you open P3 and P4 cases through the Cisco TAC Web Site.

Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses issues that are classified as priority level 1 or priority level 2; these classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer will automatically open a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to the following URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled; for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). In addition, please have available your service agreement number and your product serial number.

AccessPath, AtmDirector, Browse with Me, CCIP, CCSI, CD-PAC, *CiscoLink*, the Cisco *Powered* Network logo, Cisco Systems Networking Academy, the Cisco Systems Networking Academy logo, Cisco Unity, Fast Step, Follow Me Browsing, FormShare, FrameShare, IGX, Internet Quotient, IP/VC, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, MGX, the Networkers logo, ScriptBuilder, ScriptShare, SMARTnet, TransPath, Voice LAN, Wavelength Router, and WebViewer are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and Discover All That's Possible are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherSwitch, FastHub, FastSwitch, GigaStack, IOS, IP/TV, LightStream, MICA, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, SlideCast, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0110R)

Copyright © 2001, Cisco Systems, Inc.
All rights reserved.

(DRAFT LABEL) ALPHA DRAFT - CISCO CONFIDENTIAL